


Operating / Installation Instructions

HZMR

No. 44.HZMR.E5.10/13



valid from pump serial NoI PB13199751 onwards

Original Manual



DICKOW PUMPEN KG





Table of Contents

Table of Contents	2
1. General.....	4
2. Safety	5
2.1 Designation of Warning Notices.....	5
2.2 Intended use	6
2.3 Avoidance of foreseeable operating errors	6
2.4 Qualification of personnel.....	7
2.5 Additional safety regulations	7
2.6 Safety instructions for the operator / user	7
2.7 Safety instructions for maintenance, inspection and assembly	7
2.8 Non-observance of the instruction manual	8
2.9 Notices on explosion protection.....	8
2.10 Magnet coupling	11
3. Description.....	12
3.1 General description	12
3.2 Design code.....	12
3.3 Pump sizes	12
3.4 Identification	13
3.5 Design	14
3.6 Scope of supply.....	16
3.7 Dimensions and Weights	16
4. Handling / Storage / Disposal	17
4.1 Handling.....	17
4.2 Storage / Preservation	18
4.3 Return of pump	18
4.4 Disposal	19
5. Installation / Mounting	20
5.1 Safety Instructions	20
5.2 Foundation	20
5.3 Installation of pump unit.....	20
5.4 Piping.....	21
5.5 Insulation	23
5.6 Coupling alignment.....	23
5.7 Alignment of pump and motor.....	25
5.8 Electrical connection of the pump unit	25
6. Commissioning / Decommissioning.....	27
6.1 Commissioning	27
6.2 Operating the pump.....	29
6.3 Impeller trimming	29
6.4 Operating limits	30
6.5 Switching off the pump.....	31
6.6 Decommissioning	31
7. Maintenance / Servicing / Inspection	32
7.1 Safety regulations.....	32
7.2 Operating surveillance	33
7.3 Drainage and Disposal	35
7.4 Disassembly of pump unit	35
7.5 Inspection.....	42
7.6 Assembly of pump unit.....	43



Table of Contents

7.7	Bolt Torques.....	48
8.	Troubleshooting.....	49
9.	Interchangeability	51
10.	Sectional drawings	52
11.	Certificates	54
11.1	EC-Declaration of Conformity.....	54
11.2	Document of Compliance	55



1. General

This instruction manual describes the proper and safe usage of the pump during all operating phases.

The instruction manual does not consider local regulations. Adherence to those is the responsibility of the owner.

The name tag states pump type and size, the most important operating data as well as the pump serial number. The serial number is a precise description of the pump unit and serves as identification for all following procedures.

In the event of damage the Customer Service of Dickow Pumpen must immediately be informed in order to maintain guarantee claims.

For installation of supplied interchangeable units, the respective subchapters of "Maintenance, Servicing, Inspection" must be observed.

Applicable documents:

- Pump data sheet
- Dimensional drawing
- Sectional drawing
- Parts lists
- Sub-supplier documentation

NOTE



These operating/installation instructions are valid from pump serial number PB13199751 onwards.

If former instruction manuals should apply, this is mentioned in the pump data sheet !



2. Safety





The manual includes basic instructions for installation, operation and maintenance. Only if these instructions are strictly observed, a safe handling of pump or pump unit is guaranteed and personal injury and material damage is avoided.




All the safety instructions in this manual must be considered.

This manual must be thoroughly reviewed and completely understood by the qualified personnel / operator before attempting assembly and start-up. The manual must consistently be available on site.

Indications and plates attached to the pump must be followed and kept in legible condition.





2.1 Designation of Warning Notices

Signal word	Explanation
	signifies an imminent danger. If it will not be avoided, death or severe injury are the consequence.
	signifies a possibly dangerous situation. If it will not be avoided, death or severe injury may be the consequence.
	signifies a possibly dangerous situation. If it will not be avoided, slight or minor injury may be the consequence.
	signifies a possibly harmful situation. If it will not be avoided, danger for the pump and its function may be the consequence.

Symbol	Explanation
	General danger sign Together with a signal word, it signifies dangers in connection with death or injury.
	Dangerous voltage Together with a signal word, it signifies dangers in connection with voltage.
	Warning from magnetic field Together with a signal word, it signifies dangers in connection with magnetic fields.



2. Safety

	<p>Hot surface Together with a signal word, it signifies dangers in connection with hot surfaces.</p>
	<p>Explosion protection Gives information on protection from explosion development in hazardous area according to EC-Directive 94/9/EG.</p>
	<p>Mechanical breakdown Together with the signal word ATTENTION, it signifies dangers for the pump and its function.</p>
	<p>Notice Provides recommendation and useful information for handling the product.</p>

2.2 Intended use

The pump / pump unit may only be operated in the application area which is described in the relevant pump data sheet. This applies for instance to pumped liquid, flow, speed, pressure, temperature and motor power. Further points to be observed:

- Operate pump in technically faultless condition only.
- Never operate pump if not completely assembled.
- Never operate pump without liquid.
- Observe pump data sheet / operating manual regarding the minimum flow.
- Observe pump data sheet / operating manual regarding the maximum flow.
- Never throttle pump on suction side.
- Maximum speed is 3500 rpm (+10%) .

2.3 Avoidance of foreseeable operating errors

- Never open shut-off valves in excess of the allowable range. This would cause exceedance of the maximum flow and possible cavitation damage.
- Never exceed the allowable application limits regarding pressure and temperature which are specified in the pump data sheet.
- Consider and adhere to all safety instructions and other notices mentioned in the operating manual.



2.4 Qualification of personnel

The personnel must possess the relevant qualification for assembly, operation, maintenance and inspection of the pump unit.

Responsibility, competence and supervision must be strictly regulated by the owner.

Skill of the personnel shall be improved by training. Training course can be held by the technical staff of Dickow Pumpen.

2.5 Additional safety regulations

Besides the safety instructions mentioned in this manual, the following additional regulations apply:

- Accident prevention regulations
- Explosion proof regulations
- Safety regulations for handling hazardous materials
- Applicable standards and laws

2.6 Safety instructions for the operator / user

- Protection against contact with hot and cold components must be provided by customer.
- Coupling guard and hand guard on the pump / pump unit must not be removed during operation.
- Pump must always be earth connected / grounded.
- Protective equipment for personnel must be provided and used.
- Toxic liquid leakage must be drained off safely, without endangering individuals and environment. Legal requirements must be observed.
- Danger through electric energy must be excluded.

2.7 Safety instructions for maintenance, inspection and assembly

- Alteration works or modifications on the pump are only allowed after consulting Dickow Pumpen.
- Only original parts or parts approved by Dickow shall be used.
- Repairs on the pump / pump unit may only be done during shutdown.
- The pump casing must have cooled down to ambient temperature.
- The pump must be depressurized and drained.
- Consider the procedure for decommissioning according to chapter 6.6.
- Pumps handling products dangerous to health must be decontaminated according to chapter 4.4
- Coupling guard and hand guard must be mounted again after completion of the works.
- Works on the pump unit may be done only with disconnected electricity.
- Secure the pump unit against unintentional switch-on.



2.8 Non-observance of the instruction manual

Non-observance of this manual leads to loss of warranty and damage claims. Non-observance will involve the following risks:

- Endangering of individuals through electrical, thermal, mechanical and chemical impacts.
- Danger through explosions.
- Danger through breakdown of essential functions.
- Endangering of environment through leakage of toxic liquids.

2.9 Notices on explosion protection

DANGER



Operation in explosive areas requires stringent attention to this chapter.

- Only pumps with “Ex”-identification are allowed to be used in explosive areas.
- Pumps must be designated for this service in the pump data sheet.
- Intended use must be guaranteed.
- Inadmissible operating conditions must be avoided in any case.
- Special conditions apply for operation in compliance with EC-Directive 94/9/EC (ATEX). The “Ex”- symbol shown here marks the chapters in this manual which require special attention.

2.9.1 Surface temperature

The highest surface temperatures are to be expected at the pump casing, the containment shell and in the area of antifriction bearings. The surface temperature at the pump casing is equal to the temperature of the pumped liquid.

The surface of the bearing bracket must be uncovered. Insulation of the bearing bracket is not allowed. The containment shell temperature can be determined with Figure 1 and the following formula.



2. Safety




Fig. 1: Containment shell temperature as a function of magnet losses P_v based on water

$$T_{sp,liquid} = T_E + \Delta T_{sp,H_2O} \times \frac{c_{H_2O}}{c_{liquid}} \times \frac{\rho_{H_2O}}{\rho_{liquid}}$$

T_E = inlet temperature of product at suction flange

$\Delta T_{sp,H_2O}$ = refer to Figure 1

c_{H_2O} = specific heat capacity of water = 4,187 kJ / kgK

c_{liquid} = specific heat capacity of handled liquid [kJ / kgK]

ρ_{H_2O} = density of water = 1 kg / dm³

ρ_{liquid} = density of handled liquid [kg / dm³]

NOTE



If pumps are equipped with ceramic or PEEK containment shell, no magnet losses P_v will occur.

The surface temperature of the containment shell is almost equal to the temperature of the handled liquid.



2.9.2 Monitoring devices

The pump may only be operated within the limits given in the pump data sheet and on the name tag. In case the owner cannot maintain the operating limits, monitoring devices are required. The following risks must be considered:

- **Plugging of internal circulation channels**
The inner liquid filled area of the magnet coupling is cooled by an internal circulation. Interruption of this internal circulation through certain properties of the product (e.g. polymerization) can cause an inadmissible temperature rise.
- **Desynchronisation of the magnet coupling**
Overstressing, overheating or non-observance of the design data may result in desynchronisation of the magnet coupling. The generated heat energy may cause temperature rise of the containment shell.
- **Solids between inner magnet and containment shell**
Large solids may become wedged between inner magnet and containment shell and cause inadmissible temperature rise at the containment shell through friction.
- **Product leakage**
If a containment shell is damaged (= rare failure) and leaking product can endanger the environment, a leakage monitor should be provided.
Interaction with adjoining materials must be considered.
- **Operation below the minimum flow**
- **Operation above the maximum flow**

The following monitoring devices can be supplied:

- Level switch to avoid dry running.
- Temperature monitoring of the containment shell for controlling elevated temperatures in the containment shell.
- Power monitor for controlling minimum flow and/or maximum flow and detection of dry run and desynchronisation of the magnet coupling.
- Monitoring of the inner area of the bearing bracket to detect leakage due to containment shell damage.



2.10 Magnet coupling

DANGER

Strong magnetic field from the area of the magnet coupling or from single magnets.



Danger to life for individuals with pace maker!
Disturbance of magnetic data media, electronic devices, components and instruments!
Uncontrolled attractive force between magnetic components, tools etc.!

- A safe distance of 0,3 m minimum must be maintained.

The safe distance refers to inner and outer magnets which are not yet installed in the pump.

In mounted condition, the magnetic field is completely shielded. There is no danger through magnetic fields from an assembled pump. This refers also to pace makers.



3. Description

3.1 General description

This pump is used where ever sealless design is required. This applies for instance to dangerous, explosive, toxic and other liquids harmful to the environment which are handled in the chemical, petrochemical, oil- and gas industry.

3.2 Design code

Example: HZMR h 674 A 2 / 1,0 / 100 / 10 / 2

	Pump code
HZMR	Pump type
h	Material execution; e.g. h = 1.4408 / 1.4571
67	Pump size – nominal width discharge flange = 65mm
4	Number of stages
A	Scope of supply; e.g. A = bare shaft pump
	Magnet code
2	Material; e.g. 2 = rotor 1.4571 + containment shell 2.4610
1,0	Wall thickness containment shell [mm]
100	Magnet length [mm]
10	Circulation; 10 = internal with double-sided balance disk
2	Sleeve bearing design; e.g. 2 = shrink fitted

3.3 Pump sizes

Pump size	max. No. of stages
40	8
52	8
67	8
102	6
127	5



3. Description

3.4 Identification

3.4.1 Name tag



Fig. 2: Name tag German and English

3.4.2 Identification acc. to EC-Explosion Proof Directive




Fig. 3: ATEX-Name tag

The surface temperature does not depend on the ignition source, but on the temperature of the pumped liquid. There is no identification with a temperature class or a temperature. The symbol "X" is integrated in the identification. Chapter 2.9.1 refers to the arising surface temperatures. (Consider the notes on the pump data sheet)



3. Description

3.5 Design

Design

- multistage centrifugal pump
- horizontal installation
- end suction flange

Pump casing

- radially split
- multistage
- cast-on feet

Impeller

- closed
- enlarged suction impeller eye

Bearing

- motor end: cylinder roller bearing as loose bearing and ball bearing as fix bearing
- oil lubrication
- pump end: product lubricated sleeve bearings

Shaft sealing

- magnet coupling

Thrust load balance

- relief holes
- double-sided balance disk on discharge side

3.5.1 Magnet coupling

The drive power is transmitted by the motor - through the magnetic field lines - via the outer magnets to the inner magnet coupling. The inner and outer magnets are tied together through magnetic field lines and are therefore synchronized. No slip exists, the motor speed complies with the coupling speed.

The pump shaft with impeller and driven inner magnet is carried by wetted sleeve bearings. The SiC components have an almost unlimited service life as long as a stable fluid film is available between the sliding surfaces.

The heat in the metallic containment shells, generated through eddy currents, is dissipated through an internal circulation flow. The internal circulation is an additional safety against exceedance of boiling point in the magnet chamber and serves as a lubrication of the sleeve bearings.



3. Description

3.5.2 Balance disk




Fig. 4: double acting balance disk

A partial flow is led from pump discharge to balance chamber I (between double acting balance disk and throttle) (1) and pressurizes this chamber with the discharge pressure.

Balance chamber III (between double acting balance disk and slide bearing) (2) is pressurized with the pressure of the first stage.

In balance chamber II (between the two stationary SiC thrust bearings) the pressure is variable. The floating shaft determines the pressure depending on pressure difference between chamber I and II and the variable throttle of gap S_1 and S_2 (4).



3.6 Scope of supply

Depending on the pump execution, the following items belong to the scope of supply:

- Pump
- Elastic coupling with or without spacer
- Coupling guard
- Casted baseplate respectively welded baseframe of sturdy design
- Drive motor
- Special accessories if required

3.7 Dimensions and Weights

Dimensions and weights can be taken from the foundation plan / dimensional drawing.



4. Handling / Storage / Disposal

4.1 Handling

DANGER

Slipping of pump / pump unit from its suspension

Danger of life through components falling down !



- Lift the pump / pump unit only in horizontal position.
- Never hook up the pump on its bare shaft.
- Never hang up the pump unit on the ring screw of the motor.
- Do not stay underneath floating loads.
- Consider weight indications in the dimensional drawing.
- Observe the local accident prevention regulations.
- Use suitable and approved lifting accessories.



Fig. 5: lifting the pump

NOTE



The ring screw 919 shall be used as lifting device when handling the pump.




Fig. 6: lifting the complete pump unit





Fig. 7: lifting the pump mounted on baseplate



4.2 Storage / Preservation

ATTENTION

Damage during storage through moisture or dirt.




Corrosion and / or contamination of the pump !

- Outside storage requires a watertight cover over pump or over packed pump and accessories.

ATTENTION

Wetted, contaminated or damaged openings and joints.



Leakage or damage of the pump !

- Plugged openings should be uncovered only during installation.

The following measures are recommended for storage of the pump / pump unit:

- Store the pump in a sheltered dry place with constant air humidity.
- Turn the shaft manually once a month.

New pumps of material GGG (ductile iron) and ferritic cast steel are covered inside with anti-corrosive agent and dewatering-fluid. The maximum dry storage period is 12 months.

For storing a pump that has been in operation already, consider chapter 6.6.

4.3 Return of pump

- Drain the pump properly considering chapter 7.3.
- Rinse and clean the pump in general, especially when handling dangerous, explosive, hot or other risky liquids.
- A Document of Compliance completely filled in must always be attached to the pump. Refer to chapter 11.2.

NOTE

If required, a Document of Compliance can be downloaded under www.dickow.de.



<http://www.dickow.de/unbedenk-en.pdf>



4.4 Disposal

WARNING**Liquids dangerous to health**

Danger for individuals and environment !

- Collect and dispose rinsing water and residual liquid.
- Wear protective clothing and face mask.
- Consider the legal regulations for disposal of liquids dangerous to health.

1. Disassemble pump / pump unit.
2. Collect grease and oil.
3. Separate pump materials
4. Dispose according to the local regulations.



5. Installation / Mounting

5.1 Safety Instructions

DANGER

Improper installation in explosive area



Danger of explosion !

- Consider the local applicable explosion proof regulations.
- Consider indications on the pump data sheet and on the name tag of pump and motor.

DANGER

Strong magnetic field from the area of the magnet coupling or from single magnets



Danger to life for individuals with pace maker !

Disturbance on magnetic data media, electronic devices, components and instruments !

Uncontrolled attractive force between magnetic components, tools etc. !

- A safe distance of 0,3 m minimum must be maintained.
- Consider additional notes in chapter 2.10.

5.2 Foundation

WARNING

Installation on weak and unstable foundations



Personal injury and material damage!

- Consider sufficient concrete strength (minimum class XO) of the foundation acc. to DIN 1045.
- Place the pump unit on hardened foundation only.
- Place the pump unit on level and even surfaces only.
- Consider weight indications of dimensional drawing.

5.3 Installation of pump unit

5.3.1 Installation on foundation

1. Place the pump unit on the foundation and align it with a water-level.
Allowable deviation: 0,2 mm/m
2. Insert shims for height compensation. Always insert them both-sided near the foundation bolts between baseplate and foundation.
3. If the space between the foundation bolts is > 600 mm, insert additional shims in the middle between the foundation bolts.



5. Installation / Mounting

4. All shims must seat solidly.
5. Hook the foundation bolts into the provided bore.
6. Concrete the foundation bolts.
7. Align the base plate after concrete has hardened.
8. Tighten the foundation bolts evenly.
9. Pour the base plate with vibration-free concrete of normal graining with a water-cement-value (W/Z-value) $\leq 0,5$. Provide a pourable consistency by using a mobile solvent. Cure of concrete according to DIN 1045.

5.4 Piping

DANGER



Exceedance of the allowable loads at the pump flanges

Danger to life from leaking hot, toxic, caustic or flammable liquids.

- Do not use the pump as an anchor point for piping.
- Support piping before the pump and connect it stress-free.
- Consider allowable flange forces and moments according to chapter 5.4.2.
- Compensate expansion of the piping in case of high temperatures.

5.4.1 Suction pipe

Layout of suction pipe requires special attention. NPSH Available and NPSH Required must be clearly defined. Pay attention to the following:

- Mounting of elbows close to the pump suction must be avoided. Provide a straight pipe of minimum five suction pipe diameters.
- Never connect a larger suction pipe direct to the pump. Flow eddies reduce the free flow area of the pump. Use an eccentric reducer. Consider the Figures below.




Fig. 8: flow eddies




Fig. 9: reducer connection


- At suction lift conditions, the suction pipe must continuously slope upwards towards pump suction. Avoid air pockets.
- At flooded suction conditions, the suction pipe must slope gradually downwards to the suction flange. Avoid air pockets to ensure a complete venting.
- Maximum flow speed of 2 m/s must not be exceeded.



5. Installation / Mounting

ATTENTION

Welding beads, scale and other impurities in the piping.



Damage of the pump !


- Piping must be thoroughly cleaned before connecting the pump.
- Remove impurities from the pipes.
- If required, insert a filter.

NOTE



- Use a filter with a mesh width of 0,5 mm.
- Insert filter with a surface of minimum triple the pipe section.

5.4.2 Allowable flange forces and moments



Pump size	Suction flange											Discharge flange										
	DN	F _x [N]		F _y [N]		F _z [N]		Σ F [N]		Σ M [Nm]		DN	F _x [N]		F _y [N]		F _z [N]		Σ F [N]		Σ M [Nm]	
		GGG	GS	GGG	GS	GGG	GS	GGG	GS	GGG	GS		GGG	GS	GGG	GS	GGG	GS	GGG	GS	GGG	GS
40	100	1005	2010	900	1800	810	1620	1575	3150	735	1470	40	330	660	300	600	375	750	585	1170	490	980
52	100	1005	2010	900	1800	810	1620	1575	3150	735	1470	50	450	900	405	810	495	990	780	1560	543	1085
67	125	1185	2370	1065	2130	960	1920	1860	3720	890	1785	65	555	1110	510	1020	630	1260	990	1980	595	1190
102	150	1500	3000	1350	2700	1215	2430	2355	4710	1100	2205	100	900	1800	810	1620	1005	2010	1575	3150	735	1470
127	200	2010	4020	1800	3600	1620	3240	3135	6270	1505	3010	125	1065	2130	960	1920	1185	2370	1860	3720	890	1785

Forces and moments are based on 20°C. Temperature dependent correction values are given in the Figure below.



5. Installation / Mounting




Fig. 10: Temperature correction diagram

In case that not all acting loads reach the maximum allowable values, one of these loads may exceed the limit value under the following provisions:

- Exceedance is limited to 1,4 times the allowable value.
- For the actual forces and moments acting on the flange shall apply:

$$\left(\frac{\Sigma/F/_{actual}}{\Sigma/F/_{max. allowable.}} \right)^2 + \left(\frac{\Sigma/M/_{actual}}{\Sigma/M/_{max. allowable.}} \right)^2 \leq 2$$

5.5 Insulation

WARNING

Wetted casing parts adopt the temperature of the pumped liquid.




Risk of burns !

- Insulate casing parts
- Attach protective device

ATTENTION

Heat accumulation in the bearing bracket



Bearing damage !

- Do not insulate the bearing bracket

5.6 Coupling alignment

DANGER

Inadmissible temperatures on coupling or antifriction bearings due to misalignment of the coupling



Danger of explosion !

- Proper alignment of coupling must anytime be ensured.



5. Installation / Mounting

WARNING




Unintentional switch-on of the pump unit

Risk of injury through moving components !

- Works on the pump unit may be done only with disconnected electricity.
- Secure the pump unit against unintentional switch-on.

ATTENTION



Offset of pump shaft and motor shaft

Damage of pump, motor and coupling !

- Coupling check has always to be performed after pipe connection.
- Coupling check has also to be performed at pump units supplied on common base plate.




Fig. 11: Angular and radial misalignment of couplings




Fig. 12: Coupling alignment

1. Dismantle coupling guard.
2. Loosen support foot.
3. Place a straight edge (1) axially across the coupling half.
4. Possible radial displacement ΔK_r becomes visible as a light gap.
Better: Determine the radial misalignment by measuring the distances A and B at three points staggered by 120° .
The coupling is aligned correctly if the distance to the shaft is identical at all points.
5. Check the distance s_1 circularly between the coupling halves. The coupling is aligned correctly if the distance is circularly identical.
6. Concerning the allowable deviation Δs_1 and ΔK_r of both coupling halves, refer to the instruction manual of the coupling manufacturer !



5. Installation / Mounting

7. Mount the support foot.
8. Mount the coupling guard.

5.7 Alignment of pump and motor

WARNING



Exposed rotating coupling

Risk of injury through rotating shaft !

- Operate the pump unit only with coupling guard.
- Select the coupling guard according to corresponding standards.

DANGER



Ignition hazard through friction sparks

Danger of explosion !

- Use non-sparking material for coupling guard only to exclude flying sparks in case of contact.
- Consider EN 13463-1.

After the pump unit is installed and piping is connected, check the coupling alignment and realign motor if necessary.

Use shims for height compensation.

1. Dismantle coupling guard.
2. Check coupling alignment. Consider chapter 5.6.
3. Loosen hold down bolts of motor.
4. Place shims under the motor feet for height compensation.
5. Tighten hold down bolts of motor.
6. Check function of coupling / shaft. The coupling must easily be turnable by hand.
7. Mount the coupling guard.
8. Check the space between coupling and coupling guard.

5.8 Electrical connection of the pump unit

DANGER



Improper electrical installation

Danger of explosion !

- Electrical installation requires additionally observance of IEC 60079-14.
- Explosion proof motors shall be connected through motor protection switch only.



5. Installation / Mounting

DANGER



Working on the pump unit by unqualified personnel

Danger to life through electric shock !

- Electrical connection must be performed by qualified electrician only.
- Regulations IEC 30364 and IEC 60079 must be considered.

WARNING



Incorrect power connection

Short circuit !

- Adhere to connection conditions of local energy supply companies.

NOTE



Star-Delta starting leads to a high torque increase when switching from star to delta, this can cause decoupling of the magnets. Therefore, star-delta starting is not suitable for magnetic coupled pumps. In order to reduce the starting current, a soft-starter is recommended.

Proceedings:

1. Check for compliance of the available supply voltage with the indications on the motor name tag.
2. Select suitable connection method.
3. Check for identical rotating direction of motor and pump. Consider the rotating direction arrow of the pump !

NOTE



Observe the instruction manual of the motor !

5.8.1 Checking rotating direction

DANGER




Temperature rise through parts touching each other

Danger of explosion !

- Never check rotating direction with dry pump.
- Disconnect the pump for checking rotating direction.

ATTENTION



Wrong rotating direction of motor and pump

Damage of the pump !

- Consider the rotating direction arrow on the pump.

1. Start motor briefly. Note rotating direction of the motor.
2. Rotating direction of the motor must comply with the rotating direction arrow on the pump.
3. In case of wrong rotating direction, change the cables in the motor terminal box.



6. Commissioning / Decommissioning

6.1 Commissioning


The following points must be checked prior to start-up;

- The pump unit is correctly electronically connected to all relevant protective devices.
- The pump is filled with liquid.
- Rotating direction has been checked.
- All additional connections are connected and fully functional.
- Lubricants are checked.
- After a longer standstill period, the measures mentioned in chapter 7 "Maintenance/Service/Inspection" must be considered and performed.

6.1.1 Filling of lubrication oil

ATTENTION

Lack of lube oil in the oil reservoir of constant level oiler



Damage of antifriction bearings !

- Check oil level regularly. Oil level = centerline of sight glass
- Oil reservoir must always be sufficiently filled.
- Thread hole of constant level oiler must be horizontal




Fig. 13: filling of bearing bracket

1. Unscrew vent plug (1) (see Fig. 13).
2. Fold down the constant level oiler (2) – away from bearing bracket (3) – and hold it tight.
3. Fill in the oil through the vent plug bore (1) until the filling level reaches the connection pipe of the constant level oiler (2)
4. Fill up the oil reservoir to the maximum.



6. Commissioning / Decommissioning

5. Fold back the constant level oiler (2) to its original position.
6. Screw in the vent plug (1).
7. Check the oil level in the oil reservoir of the constant level oiler (4) after a few minutes. Oil level = centerline of sight glass. If necessary, repeat steps 4 to 6.

NOTE



Exceeding oil level causes temperature increase or oil leakage.

For filling quantity and oil quality refer to chapter 7.2.2.

6.1.2 Filling and venting the pump

DANGER

Formation of explosive atmosphere inside the pump



Danger of explosion !

- The pump must permanently be filled with liquid.
- Appropriate monitoring measures must be provided.

1. Vent and fill up pump and suction pipe with liquid. Pump is selfventing.
2. Open shut-off valve in suction pipe completely
3. Open all additional connections completely (e.g. external circulation, external flush)

6.1.3 Starting the pump

DANGER

Exceedance of allowable pressure- and temperature limits



Danger of explosion ! Leakage of hot or toxic liquid

- Never operate pump with closed shut-off valves in suction and/or discharge pipe.
- Start-up pump unit only against partially opened shut-off valve on discharge side.

DANGER

Elevated temperature through dry run



Danger of explosion !

- Never operate pump in empty condition.
- Always fill up pump properly.
- Operate pump only within the allowable operating range.



6. Commissioning / Decommissioning

1. Open shut-off valve completely in suction pipe
2. Open shut-off valve partially in discharge pipe
3. Switch on the motor. Pay attention to the synchronicity of pump and motor. Decoupling leads to low differential head and noise in the magnetic coupling.
4. When the pressure gauge indicates pressure, open shut-off valve on discharge side until the duty point is reached.
5. When the operating temperature is reached, check coupling alignment and realign if necessary.

DANGER

Elevated temperature through decoupling of the magnet coupling



Danger of explosion !

- Switch off pump unit immediately.
- Eliminate cause of malfunction.

6.2 Operating the pump

WARNING

High surface temperatures through hot liquids




Risk of burns !

- Avoid touching the pump surface.
- Wear protective clothing.

ATTENTION

Abnormal noises, vibrations, temperatures or leakage



Damage of the pump !

- Switch off the pump immediately.
- Only restart the pump unit after cause of trouble has been eliminated.

6.3 Impeller trimming

The impellers are hydraulically balanced in order to reduce thrust load. Additionally to the wear rings, thrust load is balanced by balancing holes and a double-sided balance disk.



6.4 Operating limits

DANGER

Exceedance of operating limits regarding pressure, temperature and speed



Danger of explosion ! Leaking hot or toxic liquid !

- Maintain the allowable service conditions specified in the pump data sheet.
- Avoid operation against closed shut-off valve.
- Never operate pump at a temperature higher than specified in the pump data sheet.

6.4.1 Flow rate

If not stated otherwise in the pump data sheet, the following applies:

$$Q_{\min} = 0,25 \times Q_{\text{BEP}}$$

$$Q_{\max} = 1,2 \times Q_{\text{BEP}}$$

6.4.2 Switching frequencies

DANGER

Elevated surface temperature of the motor



Danger of explosion !

- When using explosion proof motors, consider the information in the motor manual regarding switching frequencies.

The switching frequencies are defined by the maximum temperature rise of the motor and depend on the power reserve of the motor during operation and on the starting conditions.

NOTE



Read instruction manual of motor manufacturer !

6.4.3 Abrasive liquids or solids


If products containing abrasive solids are handled, increased wear is expected. The inspection intervals in this regard must be shorter than the usual ones.



6. Commissioning / Decommissioning

ATTENTION

Magnetic particles in the pumped liquid



Damage of the magnet coupling !

- Take appropriate measures to keep the containment shell area free of magnetic particles.
- If magnet filter is used, provide differential pressure measurement

6.5 Switching off the pump

1. Keep shut-off valve in suction pipe open.
2. Close shut-off valve in discharge pipe.
3. Switch off the motor and watch for steady run down.

NOTE



In case a non-return valve is installed in the discharge pipe, the shut-off valve can remain open. A counter pressure must be available.

For a longer standstill period, the following must be observed:

- Liquids which tend to polymerization, crystallization or solidification, must be drained completely.
- If required, rinse the pump with a suitable liquid.
- Close shut-off valve in the suction pipe.
- Flush connections must be closed.

6.6 Decommissioning

The pump unit remains in the piping:

- Provide sufficient amount of liquid for the test runs.
- Switch on the pump unit regularly monthly or quarterly.

The pump unit will be dismantled and stored:

- Empty the pump properly.
- Observe the safety instructions acc. to chapter 7.1 / 7.3.
- Spray the inside of the pump casing with preservation agent. Not required for stainless steel pumps.
- Spray preservation agent through suction and discharge flange.
- Plug suction and discharge flanges, e.g. with plastic caps.
- Lubricate all unpainted outside surfaces of the pump with oil and grease free of silicone. Not required for stainless steel pumps.
- Pay attention to additional notes in chapter 4.2.



7. Maintenance / Servicing / Inspection

7.1 Safety regulations

DANGER

Improper maintained pump unit



Danger of explosion !

- Maintain the pump unit regularly
- Establish a maintenance schedule

DANGER

Strong magnetic field in the area of magnet coupling or single magnets



Danger to life for individuals with cardiac pacemakers!

Disruption of magnetic data medium, electric devices, components and instruments!

Uncontrolled attractive force between magnetic components, tools etc. !

- A safe distance of minimum 0,3 m must be maintained..

WARNING

Unintentional switching-on of the pump unit



Risk of injury through moving components !

- Works on the pump unit may only be done at disconnected electricity.
- Secure the pump unit against unintentional switch-on.

WARNING

Hot liquids



Risk of injury!

- Let the pump unit cool down to ambient temperature.

WARNING

Liquids dangerous to health



Risk of injury!

- Consider legal requirements.
- Take safety measures for individuals and environment when draining the pumped liquid.
- Decontaminate the pumps.

The user must assure that maintenance, inspection and assembly is performed by qualified personnel. These persons must have studied this operating manual comprehensively.

A maintenance schedule needs a minimum of effort and may avoid expensive repairs.

Any use of force on the pump unit must be avoided.



7.2 Operating surveillance

DANGER

Elevated surface temperature through hot running antifriction bearings




Danger of explosion ! Fire hazard !

- Check antifriction bearings regularly for running noise.
- Check the lubricant level regularly.

ATTENTION

Wear caused by dry run




Damage of the pump !

- Never operate an empty pump.
- Never close the shut-off valve in suction pipe during operation.

ATTENTION

Exceedance of the allowable liquid temperature



Damage of the pump !

- Operation against closed discharge valve is not allowed.
- Consider the temperature indications in the pump data sheet.

The following requires regular checking during operation:

- The pump must always run steady and vibration-free.
- Check antifriction bearings for running noise. Vibrations, noises and increased power consumption are signs of wear.
- Check the elastic elements of the coupling.
- Clean the filter in the suction pipe regularly.

7.2.1 Lubrication / Lifetime of antifriction bearings

DANGER

Elevated surface temperature through hot running antifriction bearings or defective bearing seals



Danger of explosion ! Fire hazard !

- Check lubricant condition regularly.
- Check lubricant level regularly.

Lubrication of antifriction bearings is normally provided by mineral oil of viscosity grade ISO VG 46 or 68 with a kinematic viscosity of 46-68 mm²/s at 40°C. These can be the following mineral oils for example:

- BP Energol HL 46
- Shell Tellus 46
- Texaco Egal Premium EP 46



7. Maintenance / Servicing / Inspection

The oil filling shall be renewed the first time after 200 operating hours, then once a year.

Pump size	Bearing bracket	Magnet length [mm]	Filling Qty [l]
40 – 102	II	20 – 120	0,8
127	III	31 – 124	2,0

NOTE



If the ambient temperature is $< -20^{\circ}\text{C}$ low-viscous mineral oils, suitable for low-temperature and of viscosity grade ISO VG 5 or 10 shall be used. Observe the comments in the pump data sheet.

The calculated lifetime of antifriction bearings is – also under critical service conditions – more than 25000 operating hours.

7.2.2 Oil change

1. Place a suitable bowl for the waste oil underneath the drain plug.
2. Unscrew the drain plug from the bearing bracket and drain the oil.
3. After emptying, screw in the drain plug again.
4. Fill up oil again considering chapter 6.1.1.

WARNING



Lubricating liquids dangerous to health

Danger for individuals and environment !

- Draining requires safety measures for individuals and environment .
- Consider legal requirements concerning disposal of liquids dangerous to health.

7.2.3 Lubrication of sleeve bearings

Sleeve bearings require a stable liquid film. Checking of wear must be done:

- after dry run or cavitation.
- when vibrations, noises and power consumption are increasing.



7.3 Drainage and Disposal

WARNING

Pumped liquids dangerous to life



Endangering for individuals and environment !

- Collect flushing liquid and possible residual liquid and dispose it.
- Wear protective clothing and face masks.
- Consider legal requirements concerning disposal of liquids.

Drainage of pumped liquids through the drain plugs at the casing, through a connected shut-off valve or through a flange.

Mode of drainage and position can be taken from the dimensional drawing !

7.4 Disassembly of pump unit

7.4.1 General instructions

- Pay attention to safety instructions of chapter 7.1.
- Working on the motor requires observance of the documentation provided by the motor manufacturer.
- Consider the sectional drawings when disassembling.
- In case of damage, our service department can be contacted.

DANGER

Working on the pump unit without sufficient preparation



Risk of injury !

- Switch off the pump unit properly.
- Close shut-off valves on suction and discharge side.
- Drain and depressurize the pump.
- Flush connections must be closed.
- Let the pump unit cool down to ambient temperature.

7.4.2 Removal of driver

1. Disconnect the motor.
2. Remove coupling guard.
3. Remove the hold down bolts of the motor from the baseplate.
4. Decouple pump and motor by displacing the motor.

WARNING

Tilting the motor



Squeezing of hands and feet !

- Secure the motor by lifting or bracing.




7. Maintenance / Servicing / Inspection

7.4.3 Tools

ATTENTION

Wrong disassembly and assembly tools



Damage of components!

- Use special tools.

In order to facilitate disassembly and assembly as well as to improve protection of sensitive components, the following special tools shall be used:

Designation	Dimension / size / dwg.No.		for part No.
	pump size 40 - 102	pump size 127	
Ring screw	M12	M16	bearing frame
Hook spanner	35-60	60-90	921.2
Disassembling sleeve	60.1903	60.1904	524
Assembly tool	60.1886	60.1887	321/213
Knipex-plier wrench	46 mm / 1 3/4"	60 mm / 2 3/8"	940
Assembling sleeve	60.668	60.669	524.2
Puller incl. jack plate	60.2095/60.1883	60.2096/60.1884	322

7.4.4 Disassembly of bearing bracket




Fig. 14: disassembly of bearing bracket



7. Maintenance / Servicing / Inspection

1. Remove the motor, consider chapter 7.4.2.
2. Remove the pump from piping.
3. Place the pump in vertical position on a clean and even bench.
4. Remove hexagon nut 920.1 from intermediate flange 981.
5. Pull off the complete drive unit (1) by crane. Use of a ring screw (2) – see chapter 7.4.3 - is recommended (Figure 14)
6. Place the drive unit in vertical position on a clean and even bench.

WARNING

Tilting the pump




Squeezing of hands and feet!

- Secure the pump by lifting or bracing.

ATTENTION

Outer magnet is touching the containment shell



Damage of containment shell or outer magnet!

- Use guide rods (3).

7.4.5 Disassembly of antifriction bearings

The works according to chapter 7.4.4 are completed.

1. Clamp the bearing bracket unit with drive shaft 213 in a jaw chuck / vice. Use braces!
2. Fit the socket wrench – see chapter 7.4.3 – to the fixing screw 900.
3. Remove fixing screw 900 (left hand thread).
4. Pull the drive rotor unit out off the bearing bracket unit and place it on a clean and even bench.

WARNING

Tilting the drive rotor and bearing bracket unit



Squeezing of hands and feet!

- Secure the rotor or bearing bracket unit by lifting or bracing.




Fig. 15: Disassembly inner ring cylinder roller bearing

5. Fix the drive unit to the bench and secure it against twisting.
6. Remove key 940.1.
7. Loosen grub screw 904.4 and pull off the deflector 507.2 from drive shaft.
8. Loosen inner hexagon cap screw 914.9 and remove it together with bearing cover 360.2.
9. Press the drive shaft 213 with a press- or drilling spindle out off the bearing bracket 330.
10. Fit the pull-off device (1) – see chapter 7.4.3 – to the inner ring of cylinder roller bearing and tighten it (Figure 15).
11. Place the puller (2) and pull off the inner ring of cylinder roller bearing.
12. Reinsert key 940.1 and press it in by Knipex-plier wrench.
13. Clamp the drive shaft 213 in a jaw chuck / vice. Use braces.
14. Loosen shaft nut 921.2 with a hook spanner – see chapter 7.4.3 – (right hand thread).
15. Remove key 940.1.
16. Pull off the antifriction bearing 321.2 from drive shaft 213 using a puller.
17. Loosen inner hexagon cap screw 914.6 and remove it together with bearing cover 360.3.
18. Press the outer ring of cylinder roller bearing 322 out off the bearing bracket seat.

7.4.6 Replacing antifriction bearings

Pump size	321.2	322
40 - 102	6208	NU 2208 C3
127	6213	NU 213



7.4.7 Disassembly of containment shell

The works according to chapter 7.4.4 are completed.

WARNING

Possibly available residues of pumped liquid



Danger for individuals and environment!

- Wear protective clothing.

1. Loosen and remove inner hexagon cap screws 914.2.
2. Loosen containment shell by jack screws.

WARNING

Axial magnetic forces



Danger of squeezing fingers and hands!

- Use non-magnetic tools only.

7.4.8 Disassembly of rotor and sleeve bearing

The works according to chapter 7.4.7 are completed.

1. Retain the rotor 818.2 at the assembly holes by a suitable wrench and loosen the shaft nut 921.3 with a hook spanner (right hand thread).
2. Pull the rotor 818.2 off.

WARNING

Axial magnetic forces



Danger of squeezing fingers and hands !

- Use non-magnetic tools.
- Never place the rotor 818.2 near magnetic components.

3. Remove key 940.4.
4. Pull off locating ring 516.
5. Loosen inner hexagon cap screw 914.3.
6. Remove stationary sleeve bearing 310.1.



7. Maintenance / Servicing / Inspection

7.4.9 Disassembly of shaft sleeve

The works according to chapter 7.4.8 are completed.

WARNING

Possibly available residues of pumped liquid



Danger for individuals and environment!

- Wear protective clothing.

1. Fit the disassembling sleeve (1) – see chapter 7.4.3 – to the shaft sleeve 524.2 and tighten it (Figure 16).
2. Fit the puller and remove the shaft sleeve.
3. Remove tolerance ring 500.6.




Fig. 16: disassembling sleeve

7.4.10 Disassembly of balance disk

The works according to chapter 7.4.9 are completed.

1. Loosen inner hexagon cap screws 914.5
2. Remove intermediate flange 981 together with start-up ring 500.3.
3. Pull off intermediate ring 509.7.
4. Pull off start-up ring 500.2.

7.4.11 Disassembly of impellers

The works according to chapter 7.4.10 are completed.

1. Pull off spacer ring 504.3.
2. Remove key 940.9.
3. Support the pump underneath the stage casing 108.



7. Maintenance / Servicing / Inspection

4. Remove hexagon nuts 920.3.
5. Pull off discharge casing 107 together with start up ring 500.10, pressure ring 474 and ring 500.4.
6. Pull off shaft sleeve 524.3.
7. Remove key 940.8.
8. Remove impeller nut 922 with a hook spanner.
9. Pull off impeller 230.
10. Pull off further stage casings 108, impellers 230 and suction impeller 231.
11. Take pump shaft out off the suction casing.




Fig. 17: Disassembly of impellers



7.5 Inspection

7.5.1 Impeller / wear rings

The surfaces in the wear ring area may not have any visible grooves. Diameters of surfaces have to be measured. The total clearance in new condition is 0,5 mm. If the clearance exceeds 0,7 mm, the wear rings must be replaced.

7.5.2 Magnet assembly

Driven rotor 818.2

Surface must be free of cracks and bulges. Check parallelism by a bevelled steel edge.

Drive rotor 818.1

Replace outer magnets if mechanical or chemical damage is visible.

Torque capacity

Torques of new magnets are stated in the table below. Magnet length according to pump data sheet or name tag. For magnets that have been in operation a reduction of 10% is allowed. Larger reduction requires exchange of magnet coupling.

Pump size	Magnet length [mm]	Torque [Nm]
40 – 102 (frame size II)	20	41
	30	63
	40	90
	50	115
	60	138
	70	165
	80	190
	90	210
	100	235
	110	260
	120	280
127 (frame size III)	31	92
	62	184
	93	276
	124	368

7.5.3 SiC-Sleeve bearings / Shaft sleeves

Measure the diameters of the sliding surfaces. The maximum total clearance in new condition is as follows:

Pump size 40 - 102 = 0,194 mm

Pump size 127 = 0,176 mm

Sleeve bearing in suction flange Pump size 40 – 102 = 0,184 mm

Pump size 127 = 0,194 mm

Replace the sleeve bearing if the mentioned clearances are exceeded.



7.5.4 Bearing bracket

Measure the inner diameter of the ball bearing seats. Replace the bearing bracket if the following values are exceeded:

Pump size 40 – 102	(frame II)	→	80,009 mm
Pump size 127	(frame III)	→	120,010 mm

7.6 Assembly of pump unit

7.6.1 General instructions

- Consider the safety instructions of chapter 7.1.
- Consider the sectional drawings for assembly.
- Use new gaskets only.
- Mount gaskets without lubricants.
- Do not use assembling aid when mounting the gaskets. If necessary, use customary contact adhesive. Never use superglue.
- Lubricate fittings and screw joints with graphite or similar lubricant. Lubricants must be compatible with the pumped liquid.
- Tighten all screws properly. Consider chapter 7.7.
- When mounting the shaft sleeve, use new tolerance rings only.

WARNING

Hitting of rotor against containment shell or of containment shell against coupling half through magnetic forces




Damage of magnets and bearing ! Risk of injury !

- Strictly follow the assembling instructions.

ATTENTION

Unprofessional assembly




Damage of the pump!

- Assemble pumps / pump units under consideration of the general rules of engineering.
- Only use original spare parts.

ATTENTION

Improper mounting



Damage of outer magnet coupling !

- Use guide rods.



7. Maintenance / Servicing / Inspection

The following must be checked prior to assembly:

- All dismantled parts shall be cleaned and checked for wear.
- Damaged or worn out parts must be replaced by original spare parts.
- All sealing surfaces shall be cleaned.

7.6.2 Assembly of sleeve bearing on suction side

1. Slide the intermediate ring 509.1 and new spacer ring 504.1 up to the shaft step.
2. Insert new tolerance rings 500.7 into the keyways.
3. Fit the disassembling sleeve – see chapter 7.4.3 – to the shaft sleeve and fasten it.
4. Spray the pump shaft in the area of the tolerance rings with graphite.
5. Press the pump shaft into the shaft sleeve.
6. Slide on the locating ring 516 and new spacer ring 504.1.
7. Tighten the shaft nut 921.2.
8. Press the sleeve bearing 310.2 into the suction casing.

7.6.3 Assembly of impellers and stage casings

1. Insert the keys into the keyways. Slide the suction impeller 231 onto the pump shaft.
2. Push the pump shaft into the suction casing 106.
3. Fit the stage casing 108 with gasket 400.1 in the suction casing.
4. Push on further impellers and stage casing. Drain connections show to the bottom.
5. Tighten the impeller nut 922.
6. Insert key 940.8 into the keyway.
7. Slide on the shaft sleeve 524.3.
8. Slide on the discharge casing 107 together with start-up ring 500.10, pressure ring 474 and ring 500.4. Mount two casing screws 915 and tighten hexagon nuts 920.3 slightly.
9. Align the pump feet on a plane working table.
10. Mount the remaining casing screws 915 and tighten all hexagon nuts 920.3.
11. Insert key 940.9 into the keyway.
12. Slide on the spacer ring 504.3.

7.6.4 Assembly of balance disk

1. Slide the start-up ring 500.2 onto the pump shaft.
2. Slide on the intermediate ring 509.7.
3. Fit the intermediate flange 981 together with start-up ring 500.3 and gasket 400.2 in the discharge casing 107.
4. Tighten inner hexagon cap screws 914.5.




7.6.5 Assembly of shaft sleeve

The works according to chapter 7.6.4 are completed.

1. Push the new spacer ring 504.2 up against the intermediate ring 509.7.
2. Insert new tolerance rings 500.6 into the shaft grooves.
3. Fit the disassembling sleeve – see chapter 7.4.3 – to the shaft sleeve and tighten it.
4. Spray the pump shaft in the area of the tolerance rings with graphite.
5. Fit the shaft sleeve and press it with the assembling sleeve – see chapter 7.4.3 – and slight hammer strokes onto the tolerance rings.

ATTENTION Hammer strokes too strong



Damage of shaft sleeve !

- Use a plastic hammer.

7.6.6 Assembly of rotor and sleeve bearing

The works according to chapter 7.6.5 are completed.

1. Fix the sleeve bearing 310.1 with inner hexagon cap screws 914.3 to the intermediate flange 981.
2. Push the new spacer ring 504.2 onto the pump shaft against the shaft sleeve.
3. Slide the locating ring 516 onto the pump shaft.
4. Insert key 940.4 and press it in by using Knipex-plier wrench.
5. Slide on the rotor 818.2.
6. Retain the rotor 818.2 at the assembly holes by a suitable wrench and tighten the shaft nut 921.3 with a hook spanner (right hand thread).

7.6.7 Assembly of containment shell

The works according to chapter 7.6.6 are completed.

1. Fit containment shell. Use new gasket 400.4.
2. Tighten inner hexagon cap screws 914.2 by torque wrench.

7.6.8 Assembly of antifriction bearings

1. Heat up the inner ring of cylinder roller bearing 322 to 80 – 100°C.
2. Push the inner ring onto the drive shaft 213 up to the shaft collar.
3. Press the outer ring of cylinder roller bearing 322 into the bearing bracket 330 until limit.
4. Fit the bearing cover 360.3 and fasten it with inner hexagon cap screws 914.6.
5. Clamp the drive shaft 213 in a jaw chuck.



7. Maintenance / Servicing / Inspection

- Heat up the antifriction bearing 321.2 to 80 – 100°C and slide it onto the drive shaft 213 up to the shaft collar.




Fig. 18: Assembly antifriction bearing

- Fit the drive shaft 213 to the bearing bracket seat of antifriction bearing 321.2 and press it in with the assembling tool (1) (without spindle) – see chapter 7.4.3 – (Fig. 18). Use a press or drilling spindle.
- Screw on the shaft nut 921.2 and fasten it with a hook spanner – see chapter 7.4.3 – (right hand thread).
- Fit the bearing cover 360.2 and fasten it with inner hexagon cap screws 914.9.
- Fit the deflector 507.2 and secure it with grub screw 904.4.
- Insert the drive rotor unit into the bearing bracket unit.
- Screw in the fixing screw 900 and fasten it (left hand thread). Do not forget O-rings 412.14.

7.6.9 Assembly of bearing bracket

WARNING




Tilting the pump

Squeezing of hands and feet!

- Secure the pump by lifting or bracing.

ATTENTION



Outer magnet is touching the containment shell

Damage of containment shell or outer magnets!

- Use guide rods.



NOTE



Consider the Figure in chapter 7.4.4

1. Screw the ring screw into the thread of the drive shaft 213.
2. Lift the bearing bracket by crane.
3. Insert new O-ring 412.13.
4. Lower the bearing bracket via the guide rods to the intermediate flange 981.
5. Tighten the hexagon nut 920.1 by torque wrench.

7.6.10 Motor assembly

NOTE



The first two steps do not apply for pumps with spacer type coupling.

1. Couple pump and motor by displacing the motor.
2. Fix the motor to the baseplate.
3. Align pump and motor. Consider chapter 5.7.
4. Align coupling. Consider chapter 5.6.



7.7 Bolt Torques

	Bolt torque [Nm]	
	8.8 Standard bolts	A4-70 Standard bolts
M5	5	4
M6	9	6
M8	22	16
M10	45	30
M12	80	55
M16	195	135

Calculation basis:

- 80% Yield strength utilisation of screw material.
- Friction coefficient $\mu = 0,14$; use screw lubricant for threads and head / nut contact surface. Recommended: Klüber-paste HEL 46-450.
- Torque controlled tightening by torque wrench.

NOTE



Deviating bolt torques are indicated in the pump data sheet.

Bolt torques for screwed plugs (independent of material)

- G 1/4 = 25 Nm
- G 3/8 = 45 Nm
- G 1/2 = 75 Nm

Bolt torque for containment shell screws 914.2 = 40 Nm

Bolt torque for shaft nut 921 (independent of material), impeller nut 922 (independent of material), fixing screw 900 and casing screw 920.3:

Pump size	Bolt torque [Nm]								
	920.3		921			922			900
	St	1.4122	M17x1	M27x1,5	M38x1,5	M32x1,5	M34x1,5	M38x1,5	
40	150	170	70	90	130	110	---	---	40
50						---	120	---	
67						---	---	130	
102						---	---	130	



8. Troubleshooting

Failure	Number
Pump delivers no or not enough liquid	1
Motor is overloaded	2
Bearing temperature too high	3
Pump is leaking	4
Increased noises and vibrations	5
Inadmissible temperature increase	6
Sleeve bearing damage	7

Failure number							Problem	Elimination
1	2	3	4	5	6	7		
X				X	X		Pump or piping not completely vented or filled	Venting respectively filling
X							Shut-off valve in suction line not completely opened	Open shut-off valve
X							Air pockets in piping system	Correct piping layout Install vent valve
X							Wrong rotating direction	Exchange 2 phases of power supply
X	X						Counter pressure of the pump is higher than specified	Readjust the duty point by discharge valve Increase speed Install a larger impeller
X	X				X		Viscosity of pumped liquid is higher than specified	Consult the factory
X				X			Counter pressure of the pump is lower than specified	Trim the impeller Readjust the duty point by discharge valve
X				X	X	X	NPSHA too low	Check liquid level in suction line Improve NPSHR with inducer Reduce resistances in suction line Open shut-off valve in suction line completely
	X						Wrong speed	Check speed
		X		X			Pump unit is not aligned correctly	Check coupling alignment and correct if necessary
		X		X			Pump stressed by piping	Check piping connections and pump mounting
		X		X			Ball bearing damage	Renew antifriction bearings




8. Troubleshooting

Failure number							Problem	Elimination
1	2	3	4	5	6	7		
				X		X	Unbalance of rotating parts, e.g. impeller	Balance the parts
			X				Casing screws and screwed plugs loose	Tighten the screws and plugs Renew gaskets
		X					Coupling gap not correct	Correct coupling gap
		X					No cooling flow available from motor to antifriction bearing	Check the installation Install a cooling fan
X							Motor is bigger than nominal capacity of magnet coupling	Install smaller motor Consult the factory
X							Star delta starting	Consult the factory
X					X	X	Torque of magnet coupling devalued	Check torque
				X	X	X	Rated flow too low	Increase rated flow
X				X	X		Magnet coupling decoupled	Shut down the motor and restart Check start-up safety Consult the factory
				X		X	Increased thrust load	Check wear ring clearance Consult the factory
					X	X	Boiling point exceedance in containment shell area	Temperature monitor on containment shell Increase pressure in containment shell Increase minimum capacity




9. Interchangeability





10. Sectional drawings






10. Sectional drawings

Sectional drawing HZMR

Top magnet coupling = 20mm magnet length

Bottom magnet coupling = 120mm magnet length

Further possible magnet arrangements:





11. Certificates

11.1 EC-Declaration of Conformity

EC-Declaration of Conformity

according to EC-Machinery Directive 2006/42/EG, Annex II, No. 1A

DICKOW PUMPEN KG
Siemensstraße 22
D-84478 Waldkraiburg

Herewith we declare that the pump unit described in the data sheet

Designation: Centrifugal Pump
Type: HZMR
Size:
Design:
Serial No.:

is in compliance with all relevant provisions of the EC-Machinery Directive 2006/42/EG.

Applied harmonized standards:

EN 809:1998+A1:2009+AC:2010	EN ISO 12732-1:2008
EN ISO 12100:2010	EN ISO 12732-3:2008
EN 12162:2001+A1:2009	EN ISO 20361:2009
EN 953:1997+A1:2009	

Additionally applied standards and technical specifications:

EN ISO 15783:2003+A1:2008	VDMA 24276:2001
EN ISO 9906:2012	VDMA 24279:1993
EN 12723:2000	


Waldkraiburg,

(Jürgen Konrad, Head of Technical Dept. at DICKOW)

Jürgen Konrad is authorized to compile the technical documentation



11.2 Document of Compliance

 DICKOW PUMPEN	Document of Compliance
<p>Please fill in this statement for health innocuousness completely and attach it to the pump to be returned to the factory.</p>	
<p><u>Pump data</u></p>	
<p>Type:</p>	<p>Serial No.: PB</p>
<p><u>Reason for shipment</u></p>	
<p><u>Contamination of the pump</u></p>	
<p><input type="checkbox"/> Hazardous liquids were not handled <input type="checkbox"/> Hazardous liquids were handled</p>	
<p>Pumped liquid:</p>	
<p>The pump has been <input type="checkbox"/> cleaned <input type="checkbox"/> flushed <input type="checkbox"/> breamed</p>	
<p>The following safety measures must be taken before opening/repairing the pump:</p>	
<p><u>Customer data</u></p>	
<p>Company:</p>	<p>Phone:</p>
<p>Address:</p>	<p>Fax:</p>
<p>Name: (Block Letters)</p>	<p>E-Mail:</p>
<p>Position:</p>	<p></p>
<p>This is to certify that the above mentioned pump has been proper cleaned/flushed/breamed and repair can be performed without risk.</p>	
<p>Date:</p>	<p>Signature:</p>